

HONDA CIVIC COUPE 2001-02

SECTION INDEX

A/C Heater/Ventilation	343
A/C Refrigerant Capacities	343
ABS/Brakes	345
Air Bag System	345
Air Cleaner	346
Back Window	355
Center Console	351
Clear Coat Identification	342
Cooling	343
Cowl & Dash	350
Cruise Control	345
Electrical	349
Emission System	349
Engine	348
Engine Under Cover	348
Engine/Trans Mounts	348
Exhaust	348
Front Bumper	342
Front Door	353
Front Drive Axle	347
Front Fender	344
Front Inner Structure	344
Front Lamps	342
Front Seat	351
Front Steering Linkage/Gear	347
Front Suspension	346
Fuel Tank	357
Grille	342
Hood	342
Information Labels	345
Instrument Panel	356
Luggage Lid	350
Paint Code Location	342
Quarter Glass	356
Quarter Panel	355
Rear Body	357
Rear Bumper	358
Rear Lamps	357
Rear Seat	352
Rear Suspension	356
Roof/Pillars/Floor	351
Locker	354
Seat Belts	352
Special Cautions	342
Steering Pump	347
Steering Wheel/Column	347
Sunroof	358
Trans Oil Cooler	343
Underhood Dimensions	346
Wheel	346
Windshield	349

SPECIAL CAUTIONS

SRS

SUPPLEMENTAL RESTRAINT SYSTEM

Refer to Procedure Explanation 29 for Supplemental Restraint Air Bag Special Cautions.

SUSPENSION

Manufacturer advises that new fasteners must be used whenever old fasteners are loosened or removed.

PAINT CODE LOCATION

Paint code located on left door lock pillar.


CLEAR COAT IDENTIFICATION

All colors are clear coat.

INFORMATION LABELS

Illustration Located in Next Column

1 Label, SRS Warning		
w/ Side Air Bag	77871-S23-A80	2.35
w/o Side Air Bag	77871-SL0-A80	8.97




FRONT BUMPER

Use Procedure Explanations 1 and 28 with the following text.

Refinish Front Cover	2.1
Refinish Reinforcement Bar	1.0
R&I Bumper Assy	1.58
OH Bumper Assy (includes R&I)	2.0
Add to R&I or OH Bumper Assy w/Spoller	.3


NOTE: All Parts in this section are included in overhaul unless noted otherwise.



1 Cover, Front (P)	04711-SSP-A00Z2	2.0	198.70
2 Frame, License Plate	71145-SSA-A00	2	9.07
3 Bolt, Cover (2/Side)	R/L 91105-SSA-000	1.87	
4 Filler, Bumper	R/L 71140-SSD-A00	IOH	17.85
	L 71190-SSD-A00	IOH	17.95
5 Stay, Side Bumper	R/L 71193-SSA-000	2.22	
	L 71198-SSA-000	2.80	
6 Clip, Side (2)	91503-S23-003	2.08	
7 Absorber, Impact	71170-SSD-A00	IOH	56.95
8 Bar, Reinforcement	011130-SSA-A00Z2	#.3	117.18
	0211130-SSA-A01Z2	#.3	117.18
9 Spoiler (P)	71110-SSA-A00Z4	.3	20.30
10 Clip, Spoiler (2)	91503-S23-003		2.08
11 Damper, Front Bumper	71185-SSA-A01		13.33

GRILLE

Refinish Grille	1.0
R&I Grille Assy	#1.2
#Includes R&I Bumper Assy	




1 Grille			
Clowr Green Pearl	71121-SSP-A01ZC	#1.2	53.92
Code G95P			
Eternal Blue Pearl	71121-SSP-A01ZB	#1.2	53.92
Code 586P			
Inca Pearl	71121-SSP-A01ZH	#1.2	53.92
Code Y61P			
Nighthawk Black Pearl	71121-SSP-A01ZA	#1.2	53.92
Code 262P			
Rallye Red	71121-SSP-A01ZF	#1.2	53.92
Code R513			
Satin Silver Metallic	71121-SSP-A01ZE	#1.2	53.92
Code W422M			
Taffeta White	71121-SSP-A01ZD	#1.2	53.92
Code NH57S			
Titanium Metallic	71121-SSP-A01ZG	#1.2	53.92
Code YS22M			
#Includes R&I Bumper Assy			
2 Support, Grille	71122-SSP-A01	#.3	13.15
3 Clip, Grille (4)	691503-S23-003		2.08
4 Screw, Grille (6)	69151-144-0		1.12
5 Emblem, "H" (Adhesive)			
Factory installed	75700-SSP-E00	.2	10.63
Emblem KIT			
Dealer installed	08F20-SSP-100		49.00
*KIT Includes "CIVIC" & Front/Rear "H" Emblems			

FRONT LAMPS

COMBINATION LAMP

Aim Lamps			
R&I Combination Lamp Assy	R/L	#1.5	
#Includes R&I Bumper Assy, R&I Both Sides 1.9			

NOTE: R&R Does Not include aim lamps.




1 Lamp Assy, Combination	R 33101-SSP-A01	#1.5	204.94
	L 33151-SSP-A01	#1.5	204.54
#Includes R&I Bumper Assy, R&R Both Sides 1.9			
2 Cover, Headlamp Bulb	R/L 33126-SSP-A01		5.32
#Includes w/Combination Lamp Assy			
3 Bolt, Support (8/Side)	R/L 33403-001F-04		
4 Grommet, Screw	R/L 90682-SB0-003		.06
5 Bulb, Headlamp	R/L 33111-SSP-A01	#.2	7.49
6 Bulb, Park/Signal	R/L 34950-SSP-A01	#.2	2.26
7 Bulb, Side Marker	R/L 34951-SSP-A01	#.2	2.26
#R&R One Side Complete, R&R Both Sides .3, included in R&R Combination Lamp			
8 Socket, Park/Signal	R/L 33302-SSP-A01		9.30
9 Socket, Side Marker	R/L 33302-SSP-A01		9.50

HOOD

Use Procedure Explanations 4 and 28 with the following text.

Refinish Hood Outside	2.6
Ref. for Underseal	1.3
Refinish Hinge	R/L .3
Refinish Front Hood Moulding	#.4
R&I Hood Assy	.5
R&I Front Hood Moulding	.2



1 Panel, Hood	60100-SSD-A00Z2	1.0	308.30
2 Hinge, Hood	R 60120-SSA-000Z2	#.2	12.50
	L 60170-SSA-000Z2	#.2	12.50
#w/ Hood & Cowl Top Grille Removed			
3 Cushion, Front	R/L 74177-SSA-000		4.32
4 Cushion, Rear	R/L 74144-S01-A00		1.10
5 Seal Assy, Front Side	R/L 74142-SSA-000	#.1	12.75
	L 74192-SSA-000	#.1	12.93
6 Clip, Seal/P (7/Side)	R/L 91518-S44-003		1.52
#Included w/Front Side Seal Assy			

7 Moulding Assy, Front Hood			
Factory Installed			
Clover Green Pearl			
Code G5P	75120-SSP-A00ZC	.2	25.48
Emeral Blue Pearl	75120-SSP-A00ZB	.2	25.48
Code B2P	75120-SSP-A00ZA	.2	25.48
Incl Pearl	75120-SSP-A00ZH	.2	25.48
Code Y8P	75120-SSP-A00ZJ	.2	25.48
Nightshade Black Pearl	75120-SSP-A00ZK	.2	25.48
Code B3P	75120-SSP-A00ZL	.2	25.48
Rallye Red	75120-SSP-A00ZF	.2	25.48
Code R513	75120-SSP-A00ZE	.2	25.48
Satin Silver Metallic	75120-SSP-A00ZD	.2	25.48
Code NH623M	75120-SSP-A00ZC	.2	25.48
Tariffa White	75120-SSP-A00ZG	.2	25.48
Code W478	75120-SSP-A00ZD	.2	25.48
Titanium Metallic	75120-SSP-A00ZG	.2	25.48
Code YH52M	75120-SSP-A00ZG	.2	25.48
Dealer Installed			
Gold	08F21-SSD-100F	.2	69.00
8 Clip, Moulding¹	90157-S3N-003	.43	33
9 Bolt, Moulding¹ (4)	75120-SSP-A00	.33	33
<i>Included w/Front Hood Moulding Assy</i>			
10 Grommet, Moulding (4)	75307-SN7-090	.48	28
11 Seal Assy, Front Center	74144-SSA-000	.1	12.93
12 Clip, Seal¹ (2)	91930-S15-003		1.86
<i>Included w/Front Center Seal Assy</i>			
13 Support, Hood	74145-SSA-000	.2	6.75
14 Grommet, Support	91904-SSA-003		3.52
15 Hold, Support	90972-SSA-003		2.60
16 Latch, Hood	74120-SSA-A01		25.00
17 Cable Assy, Hood	74130-SSA-A01ZA	.8	26.00
18 Grommet, Cable¹	74134-S3C-003		2.86
<i>Included w/Hood Cable Assy</i>			
19 Clip, Cable	17706-S3C-003		.57
20 Support, Cable (2)	74231-S3A-000		8.87
21 Seal Assy, Rear Hood	74143-SSA-000	.2	12.75
22 Clip, Seal¹ (8)	91502-S8A-111		2.22
<i>Included w/Rear Hood Seal Assy</i>			

COOLING

Use Procedure Explanations 5 and 28 with the following text.

1 Radiator Assy			
USA			
Denso			
DX, EX, LX Model			
Man Trans	01 19010-PMMA-001	#.6	254.75
	02 19010-PMMA-A02	#.6	254.75
Auto Trans	01 19010-PMMA-A51	#.9	254.75
	02 19010-PMMA-A52	#.9	254.75
HX Model			
Man Trans	01 19010-PMMA-A01	#.6	254.75
	02 19010-PMMA-A02	#.6	254.75
Auto Trans	01 19010-PMMA-A51	#.9	254.75
	02 19010-PMMA-A52	#.9	254.75
Toyo			
HX Model	19010-PMMS-J51	#.6	360.93
Canada			
Man Trans	N.A.	#.6	0.00
Auto Trans	N.A.	#.9	0.00
<i>#w/Bumper Removed</i>			
2 Cap Assy, Radiator¹	19045-PA-A01		8.64
Denso	19045-PA-A01		14.77
Toyo	19045-P0B-014		1.97
3 Label, Cap¹ (a)	19046-PA-A00		1.34
<i>(a) Included w/Radiator Cap Assy</i>			
4 Cover, Radiator Cap¹	19047-PLC-003		3.78
Denso	19047-PLC-004		3.50
Toyo	19047-PLC-004		3.50
<i>Included w/Radiator Assy</i>			
5 Bracket, Radiator	R/L 74171-SEA-000		4.32
	R/L 74173-SJ-A00		2.37
6 Insulator, Upper	R/L 74172-SSA-003		1.52
7 Insulator, Lower	R/L 19101-PLC-000		20.86
8 Tank, Coolant	19109-PH1-620		2.18
9 Cap, Tank	17163-PH1-300		4.75
10 Grommet, Tank	19134-PLC-000		1.75
11 Hose, Radiator Outlet	19105-PLC-000		3.45
12 Joint, Hose	19103-PTE-000		7.45
13 Hose, Inlet	19105-PLC-000		3.45
14 Hose, Upper Radiator	19501-PLC-000	#.7	5.00
15 Hose, Lower Radiator			
Man Trans	19502-PLD-000	#.7	7.37
Auto Trans	19502-PLC-000	#.7	11.83
<i>#R/R Both 1.0</i>			

16 Stay, Lower Rad Hose	25218-PLM-000	3.72	13
17 Hose, Trans Cooler Pressure			
DX, LX, EX Model	25211-PLM-A05	#.5	5.78
Canada	N.A.	#.5	0.00
18 Hose, Trans Cooler Return			
DX, LX, EX Model	25212-PLM-A05	#.5	9.48
Canada	N.A.	#.5	0.00
<i>#HX Model-See Trans Oil Cooler Section</i>			
19 Blade, Fan			
Denso	19020-PLC-003	#.7	51.13
Toyo	19020-PLM-004	#.7	28.55
20 Shroud, Fan			
Denso	19015-PMMA-A51	#.7	72.52
Toyo	19015-PLC-004	#.7	58.50
21 Motor, Fan			
2001	19030-PA-A01	#.7	209.18
Denso	19030-PLC-004	#.7	145.95
Toyo	19030-PLC-003	#.7	177.10
<i>#R/R Complete, w/Radiator Removed Deduct .4</i>			
22 Cover, Motor			
Denso	19031-PLC-003		8.23



TRANS OIL COOLER

23 Pump Assy, Water	19200-PLM-A01	m. 2.8	60.14
24 Seal, Water Pump¹	19222-PDF-E00		20.25
<i>Included w/Water Pump Assy</i>			
25 Pipe, Upper Water	19504-PLC-000	#.5	13.92
26 Hose, Center Pipe	19503-PLC-000	#.5	14.29
27 Pipe, Lower Water	19505-PLC-000	#.5	22.78
<i>#Each Additional .2</i>			
28 O-Ring, Pipe (2)	91314-S34-000		1.90
29 Housing, Water Passage			
USA			
DX, LX Model	19410-PLM-A00	#.8	187.28
HX, EX Model	19410-PLC-000	#.8	187.28
Canada			
DX, LX Model	N.A.	#.8	0.00
Si Model	N.A.	#.8	0.00
30 Nut, Housing (2)	3020A-PH7-000		4.55
31 Sensor, Temperature	37870-PLC-004		28.45
32 Gasket, Housing			
19411-PLC-003		2.58	
19411-PLC-004		2.58	
33 Housing, Thermostat	19311-PLC-000		6.35
34 Thermostat Assy	19301-PLC-305	#.6	17.37
35 Seal, Thermostat¹	19302-PLC-A00		2.13
<i>Included w/Thermostat Assy</i>			
36 Sensor, Fan	37760-P00-004	.3	32.20
37 Bracket, Upper Harness	32747-PLC-000		2.07
38 Bracket, Lower Harness	32749-PLC-000		1.45



13 Hose, Right Return	25212-PLR-003	m. #.6	16.15
14 Hose, Left Return	25213-PLR-A02	m. #.6	2.67
<i>#R/R Both .8</i>			
15 Clamp, Hose	25216-PR3-000		3.10
16 Filter, Fluid	25243-PLR-003		17.90
17 Clam, Filter	25431-PLR-000		2.75
18 Bracket, Filter	25440-PLR-000		5.18


A/C REFRIGERANT CAPACITIES

A/C R-134a Refrigerant Capacity
2001-02: 17.6-19.4 Ozs (1.1-1.2 Lbs)

A/C HEATER/VENTILATION


Use Procedure Explanation 6 with the following text.
Evacuate & Recharge System m. 1.4
Refrigerant Recovery m. 1.3

NOTE: R/R #R/R or O/H Does Not include recover, evacuate and recharge system.



1 Condenser	80110-SSA-003	m. #.4	171.76
<i>#w/Bumper Removed</i>			
2 Bracket, Condenser	H 80107-SSA-000		1.82
	L 80108-SSA-000		5.83
3 Insulator, Upper	R/L 80107-SSO-000		3.15
4 Insulator, Lower	R/L 80175-SSO-000		2.70
<i>#Label, A/C Caution-See Information Labels Section</i>			
6 Receiver/Drier	80351-SSD-A01	m. #.5	63.00
7 Switch, Receiver/Drier	80440-SWD-401	m. #.5	43.17
8 Bracket, Receiver/Drier	80352-SSD-A00	#.2	5.87
<i>#R/R Receiver/Drier Removed</i>			
9 Pipe, Receiver/Drier	80341-SSD-A11	m. #.5	61.38
10 Pipe, Condenser	80331-SSD-A11	m. #.5	34.85
11 Hose, Section	80311-SSD-A12	m. #.6	39.69
12 Stay, Section Hose	80363-SSA-A01		42.07
13 Hose, Discharge	01 80315-SSA-013	m. #.5	34.81
	02 80315-SSD-A11	m. #.5	1.09
	80325-SSD-A12	m. #.8	58.66
	80362-SSA-A00		4.97
14 Hose, Evaporator			
15 Stay, Hose			
16 Compressor, A/C			
USA			
2001	38810-PLA-E01	m. #2.0	446.67
2002			
DX, HX Model	38810-PLA-A11	m. #2.0	431.43
DX, LX Model	38810-PLM-A11	m. #2.0	446.67
Canada			
2001	N.A.	m. #2.0	0.00
2002	N.A.	m. #2.0	0.00
17 Stator, Compressor	38816-PLM-A01	m. #2.0	145.23
18 Clutch, Compressor	38900-PLM-000	m. #2.0	188.97
<i>#R/R Complete</i>			
19 Bracket, Compressor	38930-PLC-000	#.2	26.73
20 Insulator, Compressor Heat	38355-PLM-A00	#.2	8.68
21 Belt, A/C	38920-PLR-003		5.12
<i>#Belt by Application</i>			
22 Blade, Fan			
2001	38611-PLM-A01	#.7	20.83
2002			
Kaihin	38611-PLC-J01	#.7	30.55
Mitsuba	38611-PLM-A01	#.7	20.83
23 Motor, Fan			
2001	38616-PMMA-A01	#.7	177.10
2002			
Kaihin	38616-FMM-A01	#.7	177.10
Mitsuba	38616-PLC-J01	#.7	179.77
24 Shroud, Fan			
2001	38615-PMMA-C00	#.7	26.00
2002			
Kaihin	38615-PMMA-C11	#.7	26.00
Mitsuba	38615-PMMA-C11	#.7	26.00
<i>#R/R Complete</i>			
25 Protector, Motor	38619-PMMA-A00		7.80


USA HX MODEL




26 Case, Evaporator w/ A/C			
01	79106-SSD-Y01	m. #1.0	211.60
02	79106-SSD-Y02	m. #1.0	276.05
w/o A/C	01 79106-SSP-A51	m. #1.0	211.60
	79106-SSP-A52	m. #1.0	276.05
<i>#w/Instrument Panel Removed</i>			

Illustration Located in Next Column

A/C HEATER/VENTILATION Cont'd




27 Motor, Temperature	79160-SSD-A01	m	58.08
28 Motor, Mode	01 79140-SSD-A01	m	57.18
	02 79140-SSD-A11	m	53.22
29 Evaporator	80215-SSD-001	m #2.0	200.00
30 Valve, Expansion	80220-SSA-G91	m #2.0	80.68
#R&R Complete			
31 Core, Heater	79110-SSD-A00	m #1.0	198.30
Instrument Panel Removed			
32 Plate, Heater	60211-SSD-A51	m	156.68
33 Case, Expansion Valve	79027-SSD-A01	m	3.33
34 Seal, Upper	79105-SSD-A01	m	14.37
35 Seal, Lower	79107-SSD-A01	m	21.57
36 Cover, Case	79028-SSD-A01	m	2.75
37 Cover, Duct	79029-SSD-A01	m	4.30
38 Cable, Heater Valve	79544-SSD-A00	m	4.75
39 Sensor, Evaporator	80260-SSA-941	m	13.80
40 Hose, Drain	80271-SSA-000	m	1.82



41 Case, Blower	79305-SSD-A01	m	1.4	171.08
42 Blower, Motor/Fan	79310-SSD-A01	m	.5	109.78
43 Resistor, Blower	79330-SSA-941	m		89.15
44 Seal, Upper Case	79309-SSA-003	m		95.15
45 Seal, Lower Case	79306-SSA-003	m		95.15
46 Motor, Fresh/Recirculating	79350-SSD-A01	m		56.00
47 Lid, Blower	79303-SSA-003	m		4.32
48 Plate, Frame				
w/ A/C	R 80291-SSA-003	m	25.28	
	L 80298-SSA-003	m	25.28	
w/ A/C	R 80291-SSA-101	m	45.28	
	L 80296-SSA-101	m	45.28	
49 Filter, Blower				
w/ A/C	R 80292-SSA-003	m #5	25.68	
	L 80292-SSD-A01	m #5	25.30	

#R&R Complete



50 Duct Assy, Instrument	77400-SSA-A61	#	62.67
51 Seal, Side Vent	RIL 77407-SSA-A01	#	52
#Not Included in R&R Instrument Panel			
52 Control, Mode-See Instrument Panel Section			
53 Switch Assy, A/C Defroster/Recycle	RIL 82.53		
See Instrument Panel Section			

FRONT FENDER


Use Procedure Explanations 7 and 28 with the following text.

Refinish Fender Outside	RIL	1.9	
Add to Edge	RIL	.5	
R&R Fender Assy	RIL	2	
#Includes R&R Front Bumper & R&R/R Combination Lamp Assy, R&R Both Sides 3.9			
R&R Mudguard	RIL	2	
R&R Mudguard	RIL	2	



1 Panel, Fender	R 60211-SSD-A00Z2	#2.9	150.74
	L 80261-SSD-A00Z2	#2.0	150.74
#Includes R&R Front Bumper & R&R/R Combination Lamp Assy, R&R Both Sides 4.7			
2 Support Assy, Fender	R 74105-SSA-000	4.22	
	L 74155-SSA-000	4.22	
3 Clip, Inner Support	RIL 91533-SSG-000	2.67	
#Includes w/Fender Support Assy			
4 Clip, Outer Support (Side)	RIL 91545-SSD-003	2.72	
5 Shield, Fender	R 74101-SSA-000	#4	45.90
	L 74151-SSA-000	#4	45.90
#w/Fender Removed Duct 2			
6 Clip, Shield (7/5Side)	RIL 91501-S04-003	.68	
7 Grommet, Shield (3/5Side)	RIL 90682-S80-003	.08	
Mudguard Seal			
Dealer Installed	00P00-SSD-100	89.00	
#See of 4 Front and Rear			


UNDERHOOD DIMENSIONS



FRONT INNER STRUCTURE

Use Procedure Explanations 8 and 28 with the following text.

Refinish Radiator Support Assy	RIL	1.5	
Refinish Lower Tie Bar	RIL	.5	
Refinish Side Support Panel	RIL	.5	
Refinish Hood Latch Support	RIL	.5	
Refinish Lower Tie Bar	RIL	.5	
Add to R&R Radiator Support			
w/A/C	RIL	4	
#Includes R&R A/C Condenser			
w/Trans Oil Cooler	m	#2	
#Includes R&R Trans Oil Cooler Assy			
w/Auto Trans.			
To Air Lamps			
Evacuate & Recharge System	m	1.4	
Refrigerant Recovery	m	1.3	



1 Support Assy, Radiator	60400-SSD-A00Z2s	#9.4	183.75
#Includes R&R Bumper Assy, R&R/R Combination Lamps, R&R Grille Support, Windshield Fluid Tank Assy, Coolant Tank, Air Cleaner Separator Chamber, Horns, Hood Latch, Under Engine Shield, Radiator, Fan Shroud & Motor as			

an Assy & Disconnect & Connect Hood Release Cable, Wiring & Harness			
2 Bar Assy, Upper Tie*	R 04602-SSD-A00Z2	# 2.0	122.32
3 Bracket, Fender† (s)	R 60438-SSA-300Z2		3.98
	L 60498-SSA-300Z2		3.98
(s) Included w/Upper Tie Bar Assy			
4 Bracket, Side Support†	R 60411-SSA-A00Z2		19.35
	L 60491-SSA-A00Z2		19.35
5 Panel, Side Support†	R 60485-SSD-A00Z2	# 2.0	23.70
	L 60485-SSD-A00Z2	# 2.0	20.70
6 Support, Hood Latch†	R 60434-SSA-A00Z2	# 8	22.65
7 Bar, Lower Tie†	04603-SSD-A00Z2	3.0	98.72
#Included w/Radiator Support Assy			

SIDE

Refinish Apron & Sidemember Assy	RIL	1.0	
Refinish Apron Assy	RIL	1.5	
Refinish Front Apron	RIL	.5	
Refinish Sidemember Assy	RIL	1.0	
Refinish Upper Apron Rein†	RIL	.5	



1 Apron Assy USA			
DX, LX, EX Model	01 R 60650-SSA-A00Z2s	#7.5	240.00
	L 60750-SSA-A00Z2s	#8.0	252.00
	02 R 60650-SSA-A00Z2s	#7.5	240.00
	L 60750-SSA-A00Z2s	#8.0	84.53

HX Model			
Man Trans	01 R 60650-SSA-A00Z2s	#7.5	240.00
	L 60750-SSA-A00Z2s	#8.0	252.00
	02 R 60650-SSA-A00Z2s	#7.5	84.63
	L 60750-SSA-A00Z2s	#8.0	114.50
Auto Trans	01 R 60650-S9W-A10Z2s	#7.5	114.50
	L 60750-SSA-A00Z2s	#8.0	252.00
	02 R 60650-S9W-A10Z2s	#7.5	114.50
	L 60750-SSA-A10Z2s	#8.0	84.63
Canada	R N.A.	# 7.5	0.00
	L N.A.	# 8.0	0.00

#w/Side Support Panel or Radiator Support Removed			
Deduct 1.0			
2 Extension, Apron†	R 60613-SSA-A00Z2s	2.0	24.27
	L 60713-SSA-A00Z2s	2.0	24.09
3 Apron, Front†	R 04642-SSA-300Z2s	#3.0	51.28
	L 60711-SSA-300Z2s	#3.5	18.15

#Included w/Apron Assy			
#w/Side Support Panel or Radiator Support Removed			
Deduct 1.0			
4 Reint, Upper Apron	R 60614-SSA-300Z2s	2.0	18.24
	L 60714-SSA-300Z2s	2.0	18.24

5 Sidemember Assy USA			
DX, EX, LX Model	01 R 60810-SSA-A00Z2s	#8.0	285.90
	L 60910-SSA-A00Z2s	#8.0	298.58
	02 R 60810-SSD-A00Z2s	#8.0	306.55
	L 60910-SSD-A00Z2s	#8.0	284.42

HX Model			
Man Trans	01 R 60810-SSA-A00Z2s	#8.0	285.90
	L 60910-SSA-A00Z2s	#8.0	298.58
	02 R 60810-SSD-A00Z2s	#8.0	306.55
	L 60910-SSD-A00Z2s	#8.0	284.42

Auto Trans			
	01 R 60810-S9W-300Z2s	#8.0	294.35
	L 60910-SSA-A00Z2s	#8.0	298.58
	02 R 60810-S9W-300Z2s	#8.0	340.13
	L 60910-SSD-A00Z2s	#8.0	284.42

Canada	01 RIL N.A.	#8.0	0.00
	02 RIL N.A.	#8.0	0.00

#w/Apron Assy Removed Deduct 3.0, w/Side Support Panel or Radiator Support Removed Deduct 1.0

6 Reint, Sidemember† USA			
DX, EX, LX Model	R 04606-SSA-A00Z2s	1.5	191.53
	L 04616-SSA-A00Z2s	1.5	191.53


HX Model			
Man Trans	R 04606-SSA-A00Z2s	1.5	191.53
	L 04606-SSD-A00Z2s	1.5	191.53
Auto Trans	R 04616-SSA-A00Z2s	1.5	191.53
Canada	RIL N.A.	# 1.5	0.00

7 Reint, Sidemember†	01 R 60811-SSA-A00Z2s	#8.0	49.12
	L 60911-SSA-A00Z2s	#8.0	47.50
	02 R 60811-SSA-A00Z2s	#8.0	49.12
	L 60911-SSA-A00Z2s	#8.0	47.50

8 Bracket, Sidemember†	R 60629-SSA-A00Z2	20.00	
	L 60629-SSA-A00Z2	20.00	
9 Extension, Sidemember†	R 04610-SSA-A00Z2s	1.0	41.42
	L 04615-SSA-A00Z2s	1.0	41.42


10 Stay, Sidemember	R	60637-SSA-000Z	13.80
11 Bracket, Sidemember	L	60637-SSA-000Z	13.80
12 Outrigger, Sidemember	R	04605-SSA-A00Z	8.5 260.53
13 Bracket, Engine Mount	L	04605-SSA-A00Z	8.5 212.87
*Included w/Sidemember Assy			
14 Base, Battery Tray	R	60630-SSA-A00Z	#2 15.67
#Battery Removed			

SUB-FRAME



1 Sub-Frame			
USA			
DX, EX, LX Model			
Man Trans	50200-SSA-A03 m	#8.0	533.85
HX Model	50200-SSA-A71 m	#8.0	440.42
Man Trans	50200-SSA-A03 m	#8.0	533.85
Auto Trans	50200-SSA-A63 m	#8.0	328.20
Canada	50200-SSA-A03 m	#8.0	533.85
*Includes R&R Steering Gear Assy, R&R Stabilizer Bar & Control Arms, Not Included in O/H Suspension			
2 Damper, Rear	01 50205-SSA-A20		28.17
	02 50205-SSA-A00		33.95
3 Bolt, Sub-Frame (4)	90175-SSA-000		4.87

ELECTRICAL COMPONENTS



1 Box Assy, Main Fuse			
USA			
DX, HX Model	38250-SSP-A01 m		194.08
LX, EX Model	38250-SSP-A11 m		194.08
Canada			
DX Model	N.A.	m	0.00
LX, SI Model	N.A.	m	0.00
2 Block, Fuse# (a)			
40 Amp	38231-S04-961		3.38
3 Fuse, Main# (a)			
7.5 Amp	98200-40750		.52
10 Amp	98200-41000		.52
15 Amp	98200-41500		.52
20 Amp	98200-42000		.52
30 Amp	98200-43000		.52
4 Fuse, Main# (1)			
40 Amp	38212-SMM-003		6.24
80 Amp	38212-SMM-003		7.14
5 Puller, Fuse# (1)			
6 Cover, Upper	38251-SSP-A01		1.30
7 Cover, Lower	38251-SSP-A01		1.30
*Included w/Main Fuse Box Assy			
8 Bracket, Frl Fuse Box	38253-SSA-000		2.22
9 Bracket, Rear Fuse Box	38251-SSA-000		1.90
10 Relay	38792-SE0-003		3. 23.32

*Order by Application


AIR BAG SYSTEM

NOTE 1: R&R Does Not include disable and enable or diagnose Air Bag System.

NOTE 2: Refer to Procedure Explanation 30 for Supplemental Restraint/Air Bag Systems Component Inspection and Replacement Information.

FRONT

Disable & Enable Air Bag System	m	3
Diagnose Air Bag System (If Required)	m	2.0



1 Reel, Cable USA			
DX Model	01 77900-SSA-A01 m	#8	180.52
	02 77900-SSA-A03 m	#8	184.91
EX, HX, LX Model	01 77900-SSA-A11 m	#8	180.52
	02 77900-SSA-A13 m	#8	164.91
Canada			
DX Model	01 N.A.	m	#8 0.00
LX, SI Model	02 N.A.	m	#8 0.00
*Included w/ABS			
2 Module, Driver Air Bag	06770-SF-A802A m	#3	584.92
Non-Autoliv	06770-SSA-A02A m	#3	584.92
3 Module, Passenger Air Bag			
Black	06780-SSA-A82A m	#5	622.19
White	06780-SSA-A82B m	#5	622.19
*Included in R&R Instrument Panel			
4 Control Unit, SRS			
NEC	77960-SSA-A82 m	#4	190.63
Siemens			
w/Side Air Bag	01 77960-SSP-A91 m	#4	330.00
	02 77960-SSP-A11 m	#4	255.65
w/o Side Air Bag	02 77960-SSA-A81 m	#4	190.63
5 Sensor, Front Impact			
	R 77930-SSA-A81 m	#2	77.65
	L 77940-SSA-A81 m	#2	77.65

#W/Fender Liner Removed

SIDE

Disable & Enable Air Bag System	m	3
Diagnose Air Bag System (If Required)	m	2.0

*Order by Application

1 Module, Side Air Bag			
Driver Side			
Black	06786-SSA-A802B m	#7	203.99
Beige	06786-SSA-A802C m	#7	203.99
Passenger Side			
Beige	06783-SSA-A802B m	#7	203.99
Black	06783-SSA-A802C m	#7	205.92
*W/Seat Removed			
2 Holder, Module			
Driver Side			
	81128-SSA-J01		10.38
Passenger Side			
	81128-SSA-J01		67.30
3 Sensor, OPDS			
	01 R 81334-SSA-J01 m	#7	191.82
	02 R 81334-SSP-A01 m	#7	238.00
*W/Seat Removed			
4 Cover, OPDS			
	R 81129-SSA-J01 m		1.43
	R 81312-SSA-000 m		11.05
5 Harness, OPDS			
	01 R/L 77970-SSA-A91 m	#2	63.58
	02 R/L 77970-SSP-A11 m	#2	124.70


#W/Seat & Center Pillar Lwr Trim Panel Removed

ABS/BRAKES

Bleed System w/ABS	m	5
w/o ABS	m	3

NOTE: R&R Does Not include bled system.

Illustration Located in Next Column




4 Bracket, Module			
	57115-SSA-A02	#2	21.65
*W/Module Removed			
5 Cylinder Assy, Brake Master			
USA			
DX, HX, LX Model	46100-SSD-L01 m	1.1	107.88
EX Model	46100-SSD-A51 m	1.1	107.88
Canada			
DX Model	N.A.	m	1.1 0.00
LX Model	N.A.	m	1.1 0.00
w/ABS	N.A.	m	1.1 0.00
w/o ABS	N.A.	m	1.1 0.00
SI Model	N.A.	m	1.1 0.00
w/ABS	N.A.	m	1.1 0.00
w/o ABS	N.A.	m	1.1 0.00
6 Cap, Cylinder#			
	46662-SSA-009		6.73
7 Diaphragm, Cylinder#			
	46699-SSA-003		3.00
8 Filter, Cylinder#			
	46656-S2K-000		5.93
*Included w/Brake Master Cylinder Assy			
9 Booster Assy, Brake			
USA			
DX, HX, LX Model	01469-SSD-010 m	#1.7	315.73
EX Model	01469-SSD-A09 m	#1.7	227.70
Canada			
DX, LX Model	N.A.	m	#1.7 0.00
SI Model	N.A.	m	#1.7 0.00
*Includes R&R Brake Master Cylinder			
10 Seal, Booster#			
USA			
DX, HX, LX Model	46185-S04-J01 m		1.28
EX Model	46185-SE0-003 m		3.20
Canada			
DX, LX Model	N.A.	m	0.00
SI Model	N.A.	m	0.00
11 Gasket, Booster#			
	46191-S2K-000 m		1.63
*Included w/Brake Booster Assy			
12 Hose, Booster			
USA			
DX, HX, LX Model	01 46402-SSA-L01 m		32.38
	02 46402-SSA-L02 m		32.38
EX Model	46402-SSA-A02 m		24.65
Canada			
DX, LX Model	N.A.	m	0.00
SI Model	N.A.	m	0.00
13 Sensor, Front ABS			
	01 R 57450-SSA-013 m	#3	94.13
	02 R 57450-SSA-013 m	#3	94.13
	02 R 57450-SSD-013 m	#3	30.00
	01 R 57470-SSA-013 m	#3	94.13
	02 R 57475-SSA-013 m	#3	94.13
	02 R 57475-SSD-013 m	#3	30.00
	02 R 57475-SSD-013 m	#3	30.00

CRUISE CONTROL

USA


DX, EX, LX MODEL



1 Actuator, Cruise Control	38520-PLR-A02 m	#5	183.65
2 Bracket, Frl Actuator	36913-PLR-A00		19.42
3 Bracket, Ctr Actuator	36913-PLR-A00Z		5.30
4 Bracket, Rear Actuator	36913-PLR-A00		2.90
5 Cable, Actuator	17880-PLR-A01 m	#5	16.72
6 Switch, Cruise Control-See Steering Wheel/Column Section			


CRUISE CONTROL Cont'd

USA HX MODEL



1 Actuator, Cruise Control	36511-PLM-A01 m	5	195.80
2 Bracket, Frt Actuator	36535-PLM-A00		2.90
3 Bracket, Rear Actuator	36536-PLM-A00		2.56
4 Cover Assy, Actuator	36921-PLM-A01		24.15
5 Seal, Front (2)	36523-PLM-A01		30.20
6 Seal, Rear	36522-PLM-A01		30.20
*Included w/Actuator Cover Assy			
7 Cable, Actuator	17860-PLM-A01 m	5	25.17
8 Control Unit	36700-SSP-A01 m	5	112.93
Man Trans	36700-SSP-A11 m	5	112.93
9 Switch, Cruise Control-See Steering Wheel/Column Section			

CANADA LX, SI MODEL




1 Actuator, Cruise Control	N.A.	m	5	0.00
2 Bracket, Frt Actuator	N.A.	m	5	0.00
3 Bracket, Rtr Actuator	N.A.	m	5	0.00
4 Bracket, Rear Actuator	N.A.	m	5	0.00
5 Cable, Actuator	N.A.	m	5	0.00
6 Switch, Cruise Control-See Steering Wheel/Column Section				

WHEEL

Use Procedure Explanation 10 with the following text.

STEEL WHEEL

Refresh Wheel	5
Add to R&I Spare Wheel & Tire Assy	2



1 Wheel, Steel	42700-SSD-A01	3	45.95
1x5.5	42700-SSD-A11	3	50.95
2 Cover, Wheel	44733-SSD-A01		21.40
1x6.5 Wheel	44733-SSA-A10		66.23
3 Nut, Lug	90304-SAO-981		4.75
*Order by Application			
4 Stem, Valve	42753-SBB-961		.75


ALLOY WHEEL

Add to R&I Spare Wheel & Tire Assy	2
------------------------------------	---



1 Wheel, Alloy	42700-SSP-A01	3	166.40
2 Cap, Center	44732-SSP-A00		7.75
3 Nut, Lug	90304-SAS-013		5.50
4 Stem, Valve	42753-SBB-961		.75

SPARE WHEEL & HARDWARE



1 Wheel, Spare	01 42700-SRB-A45	55.48
1x4x	02 42700-SSD-A51	155.55
1x4x	02 42700-SSD-A11	49.85
2 Label, Spare Tire Caution-See Information Labels Section		.75
3 Stem, Valve	42753-SBB-961	5.53
4 Hold-Down, Spare Wheel	83653-S10-000	4.78
5 Washer, Hold-Down	83850-S13-000	
6 Tool Kit		
USA		
DX, HX, LX Model	88000-SM2-C02ZA	8.43
EX Model	89000-S01-A10	10.40
Canada		
DX, LX Model	N.A.	0.00
SI Model	N.A.	0.00
7 Wrench, Sunroof*	71959-SAT-890	0.77
8 Wrench, Lug*	89211-SB3-003	11.00
9 Bar, Jack*	89320-SL0-003	18.10
10 Bag, Tool*	89101-S01-A10	10.30
*Included w/Tool Kit		
11 Jack Assy	89310-SSD-A01	36.63
12 Plate, Jack Caution*	89311-SSD-A01	3.28
*Included w/Jack Assy		


FRONT SUSPENSION

Use Procedure Explanation 11 with the following text.

R&I Suspension (One Side)	R/Lm	2.0
O/H Suspension (Includes R&I)	R/L	3.0
One Side	m	6.2
Both Sides	m	12.2
Adjust Four Wheel Alignment	m	6.6
Adjust Front Alignment	m	1.3
W/Hub to Adjust Alignment	m	1.3
W/Upper Covers	m	2
Bleed Brake System	m	5
w/ABS	m	3
w/ABS	m	3

NOTE 1: R&I/R&R or O/H Does Not include alignment or bleed brake system.

NOTE 2: All Parts in this section are included in overhaul unless noted otherwise.



1 Rotor, Brake	R/L 45251-SK7-A10 m	6.5	88.09
*R&R Both Sides 1.0			
2 Sensor, Front ABS-See ABS/Brakes Section			
3 Hub Assy, Wheel	R/L 44600-SSD-A00 m	6.8	31.07
*Includes R&R Rotor, R&R Both Sides 2.4			
4 Stud, Wheel (e) (4/Side)	R/L 90113-SAO-006 m	3.83	
*Included w/Wheel Hub Assy			
*Order by Application			
5 Circlip	R/L 90591-SP3-A00 m	11.8	7.45
6 Bearing	R/L 44300-SSA-008 m	8.43	46.23
*R&R One Side Complete, Includes R&R Rotor, R&R Both Sides 3.4			
7 Caliper, Brake			
DX, HX, LX Model	R 45016-SSD-J00R0M	4.5	R91.67
EX Model	R 45016-SSD-A00RM	4.5	R91.67
Canada	L 45019-SSD-A00RM m	4.5	R91.67
DX, LX Model	R/L N.A.	m	5.0 0.00
SI Model	R/L N.A.	m	5.0 0.00
*R&R Both Sides .8, w/Rotor Removed Deduct .3			
8 Pad Set, Brake	R/L 45022-SSD-A00 m	1.0	44.95
*Deduct .5 for Each Caliper Removed			

9 Hose, Brake R 01464-SSP-A01 m #3 20.55

L 01465-SSP-A01 m #3 20.55

#w/Caliper Removed Deduct 2

10 Shield, Splash R/L 45255-S01-A00 m #2 12.69

#w/Hub Removed


11 Knuckle Assy, Steering R 51210-SSA-J10 m #1.8 168.30

L 51215-SSA-J10 m #1.8 168.30

#Includes R&R Hub, Bearing & Rotor, R&R Both Sides

12 Boot, Dust* R/L 51225-SSA-003 m 2.17

*Included w/Steering Knuckle Assy



13 Arm Assy, Control R 51350-SSA-A03 m #1.3 87.25

L 51360-SSA-A03 m #1.3 87.25

#w/Knuckle Removed Deduct .5, R&R Both Sides 2.2

14 Bushing, Front* R/L 51391-SSA-024 m #2 10.15

L 51392-SSA-004 m #2 7.93

*Included w/Control Arm Assy

#w/Control Arm Removed

16 Bolt, Control Arm (2/Side) R/L 90118-SSA-000

L 51323-SSA-003 m #4 11.73

17 Link, Stabilizer R 51321-SSA-005 m #4 11.73

L 51321-SSA-005 m #4 11.73

USA

DX, LX Model 51300-SSD-A11 m #1.0 76.50

EX, HX Model 51300-SSD-A01 m #1.0 76.50

Canada

DX, LX Model N.A. m #1.0 0.00

SI Model N.A. m #1.0 0.00

*Not Included in O/H

19 Bushing, Stabilizer 51306-SSD-005 m #3 1.47

20 Bracket, Bushing R/L 51308-SSA-000 m #3 2.35

#R&R One Side Complete, Included in R&R Stabilizer

Bar, Not Included in O/H

21 Strut Assy*

DX Model

Man Trans R/L N.A. m #1.3 0.00

Auto Trans R/L N.A. m #1.3 0.00

LX Model

w/ABS R/L N.A. m #1.3 0.00

w/ABS R/L N.A. m #1.3 0.00

SI Model

w/ABS R/L N.A. m #1.3 0.00

Man Trans R/L N.A. m #1.3 0.00

Auto Trans R/L N.A. m #1.3 0.00

w/ABS R/L N.A. m #1.3 0.00

*USA-Service by Components

#w/Knuckle Removed Deduct .9, R&R Both Sides 2.4

Canada

DX, HX, LX Model 01 R 51605-SSD-A05 m #1.7 104.69

01 L 51606-SSD-A02 m #1.7 104.69

02 R 51605-SSD-A07 m #1.7 104.69

01 L 51606-SSD-A07 m #1.7 104.69

01 R 51605-SSA-A05 m #1.7 104.69

02 R 51605-SSA-A07 m #1.7 104.69

01 L 51606-SSA-A07 m #1.7 104.69

Canada

DX Model 01 R/L N.A. m #1.7 0.00

LX, SI Model 01 R/L N.A. m #1.7 0.00

w/ABS 01 R/L N.A. m #1.7 0.00

02 R/L N.A. m #1.7 0.00

02 R/L N.A. m #1.7 0.00

23 Spring, Coil*

USA

2001

DX, HX Model R 51401-SSA-G13 m #1.7 51.37

Man Trans R/L 51401-SSA-G23 m #1.7 51.37

Auto Trans R/L 51401-SSA-G23 m #1.7 51.37

EX Model R 51401-SSA-G23 m #1.7 51.37

Man Trans R/L 51401-SSA-G23 m #1.7 51.37

Auto Trans R/L 51401-SSA-G23 m #1.7 51.37

LX Model R/L 51401-SSA-G23 m #1.7 51.37

2002

DX, LX Model EX Model R 51401-SSA-A11 m #1.7 71.52


Man Trans R/L 51401-SSA-A11 m #1.7 71.52

Auto Trans R/L 51401-SSA-A11 m #1.7 71.52

RK Model			
Man Trans	R/L	51401-SSA-A11	m #1.7 71.52
Auto Trans	R/L	51401-SSA-A21	m #1.7 71.52
Canada			
DX Model			
Man Trans	R/L	N.A.	m #1.7 0.00
Auto Trans	R/L	N.A.	m #1.7 0.00
LX Model	R/L	N.A.	m #1.7 0.00
SI Model			
w/ABS	R/L	N.A.	m #1.7 0.00
Man Trans	R/L	N.A.	m #1.7 0.00
Auto Trans	R/L	N.A.	m #1.7 0.00
w/ABS	R/L	N.A.	m #1.7 0.00
2002	R/L	N.A.	m #1.7 0.00
24 Cover, Dust ¹	R/L	51722-SSA-014	m #1.7 9.48
25 Rubber, Upr Spring Seat ¹	R/L	51688-SSA-014	m #1.7 11.35
26 Rubber, Lwr Spring Seat ¹	R/L	51402-SSA-024	m #1.7 13.27
27 Rubber, Shock Mount ¹	R/L	51726-SSA-004	m #1.7 17.30
28 Base, Strut Mount ¹	R	51920-SSA-024	m #1.7 28.48
	L	51925-SSA-014	m #1.7 28.48
#R&R One Side Complete, w/Knuckle Removed Deduct 3.2			
#R&R Both Sides 3.2			
29 Nut, Strut Mount	R/L	90213-SJ6-004	m 2.48
<i>1 Included w/Strut Assy (Canada)</i>			

FRONT DRIVE AXLE

R&L Axle Shaft Assy	R/Lm #1.3
O/H Axle Shaft Assy (Includes R&L)	R/Lm #2.2
#w/Knuckle Removed Deduct 1.0		




1 Axle Assy, Drive USA			
DX, HX, LX Model			
Man Trans	R	44305-SSD-A01	m #1.3 311.23
	L	44306-SSD-A01	m #1.3 306.93
Auto Trans	R	44305-SSD-A11	m #1.3 306.63
	L	44306-SSD-A11	m #1.3 306.63
EX Model			
Man Trans	R	44305-SSD-A51	m #1.3 306.63
	L	44306-SSD-A51	m #1.3 306.63
Auto Trans	R	44305-SSD-A61	m #1.3 306.63
	L	44306-SSD-A61	m #1.3 306.63
Canada			
DX Model			
Man Trans	R/L	N.A.	m #1.3 0.00
Auto Trans	R/L	N.A.	m #1.3 0.00
LX Model			
w/ABS	R/L	N.A.	m #1.3 0.00
Man Trans	R/L	N.A.	m #1.3 0.00
Auto Trans	R/L	N.A.	m #1.3 0.00
w/ABS	R/L	N.A.	m #1.3 0.00
Man Trans	R/L	N.A.	m #1.3 0.00
Auto Trans	R/L	N.A.	m #1.3 0.00
SI Model			
w/ABS	R/L	N.A.	m #1.3 0.00
Man Trans	R/L	N.A.	m #1.3 0.00
Auto Trans	R/L	N.A.	m #1.3 0.00
w/ABS	R/L	N.A.	m #1.3 0.00
Man Trans	R/L	N.A.	m #1.3 0.00
Auto Trans	R/L	N.A.	m #1.3 0.00
#w/Knuckle Removed Deduct 1.0			
2 Joint Assy, Outer¹ USA			
DX, HX, LX Model			
R/L	R/L	44014-SSD-A01	m #5.5 92.60
EX Model	R/L	44014-SSD-A51	m #5.5 93.99
Canada			
w/ABS	R/L	N.A.	m #5.5 0.00
w/ABS	R/L	N.A.	m #5.5 0.00
3 Boot, Outer ¹ (a)	R/L	44018-SSD-A01	m #5.5 40.00
<i>(a) Included w/Outer Joint Assy</i>			
#R&R One Side Complete, w/Axle Shaft Assy Removed			
4 Joint, Inner¹			
Man Trans	R	44310-SSD-A01	m #5.5 107.86
	L	44310-SSD-A31	m #5.5 107.86
Auto Trans	R	44310-SSD-A11	m #5.5 107.86
	L	44310-SSD-A21	m #5.5 107.86
5 Boot, Inner ¹ (a)	R/L	44017-SSD-A01	m #5.5 40.00
<i>(a) Order by Application</i>			
#R&R One Side Complete, w/Axle Shaft Assy Removed			
6 Damper, Dynamic ¹	R/L	44351-SSA-J01	m 17.20
<i>1 Included w/Drive Axle Assy</i>			

FRONT STEERING LINKAGE/GEAR


R&L Steering Gear	2.6
O/H Steering Gear (Includes R&L)	3.9
NOTE 1: R&R/R or O/H Does Not include adjust wheel alignment.		

NOTE 2: All Parts in this section are included in overhaul unless noted otherwise.



1 Gear Assy	01	53601-SSD-A04	m 2.6	637.50
	02	53601-SSP-A01	m 2.6	632.30
2 Boot, Center ¹	01	06338-SSA-H01	m	16.07
3 Housing, Pressure ¹	01	53608-SSD-A01	m 3.0	189.80
4 Tube, Steering ¹	01	53611-SSD-A01	m 3.9	94.92
5 Screw, Lock ¹	R	53471-SSA-001	m	7.32
6 Ring, Lock ¹	L	R 53663-SSA-003	m	3.45
7 Bracket, Steering ¹	01	53626-SSD-A01	m 3.9	113.37
	02	53626-SSP-A02	m 3.9	111.88
8 Bracket, Tie Rod ¹	R	53645-SSA-003	m	20.75
9 Seal, Bracket ¹	R	06338-SSA-H01	m	23.05
10 Boot, Outer ¹	R	06337-SSA-H01	m #6	4.07
<i>1 Includes R&R Tie Rod End</i>				
11 Guide, Pressure ¹		53416-SSA-003	m	17.25
12 Spring, Pressure ¹		53419-S04-G51	m	1.88
13 Screw, Pressure ¹		53414-SSA-003	m	2.75
14 Nut, Pressure ¹		53428-SSA-000	m	2.15
15 Housing, Valve ¹		53645-SSA-001	m	89.47
16 Valve, Steering ¹	R	53641-SSD-A01	m	151.85
17 Tube, Oil Feed ¹	R	53670-SSD-A01	m	7.20
	L	53671-SSD-A01	m	6.28
<i>1 Includes w/Gear Assy</i>				
18 Grommet, Gear	R/L	53501-SSD-A00	m	2.30
19 Bracket, Steering Rack	R	53424-SSD-A01	m	21.66
	L	53438-SSA-A50	m	25.12
20 Collar, Bracket	R/L	53686-SSA-010	m	3.72
	L	53686-SSA-901	m	3.57
21 Bushing, Collar	R/L	53685-SSA-000	m	1.45
	L	53685-SSA-000	m	.63
22 Clamp, Gear	R/L	53435-SSA-A00	m	2.95
23 Cover, Steering Rack	R/L	53692-SSA-A02	m	6.53
24 Rod Assy, Tie Rod	R/L	53541-SSA-000	m #6	66.30
Includes R&R Outer Boot				
25 End Assy, Tie Rod ¹	R/L	53541-SSA-003	m 3	45.00
26 Boot, Tie Rod End ¹ (a)	R/L	53546-SSA-003	m	1.55
<i>(a) Included w/Tie Rod End Assy</i>				
27 Rod, Tie ¹	R/L	53541-SSA-003	m #6	51.77
<i>1 Includes w/Tie Rod Assy</i>				
<i>Includes R&R Outer Boot</i>				

STEERING PUMP




1 Pump, Steering	51100-PLA-013PM	m	R298.08	
2 Pulley, Pump ¹	56465-PLM-003	m #2	13.53	
<i>1 Order by Application</i>				
#w/Steering Pump Removed				
3 Bracket, Pump	56997-PLM-003	m	26.48	
4 Belt, Drive	56992-PLM-003	#5	8.65	
#w/AC Add. 1				
5 Reservoir, Fluid	53701-SSD-A02	m	35.00	
6 Cap, Reservoir	53702-SSD-A02	m	9.8	
7 Bracket, Reservoir	53711-SSD-A02	m	7.17	
8 Hose, Pressure	01	53713-SSP-A01	m	65.78
	02	53713-SSP-A02	m	65.78

9 Switch, Pressure	01	58490-P2C-A82	m	17.13
	02	56490-PLA-A01	m	84.37
10 Tube, Suction		53731-SSD-A01	m	8.00
11 Hose, Return		53732-SSD-A01	m	698.30
12 Pipe, Return		53730-SSD-A00	m	8.57

STEERING WHEEL/COLUMN

All Parts in this section are included in overhaul unless noted otherwise.


WHEEL/TRIM



1 Wheel, Steering	78501-SSD-A61ZM	m #5	73.43
2 Trim, Body USA			
DX Model	7816-SSD-A61ZM	m #5	3.35
EX, LX Model	7818-SSD-A61ZM	m #5	3.35
Canada	N.A.	m #5	0.00
DX Model	N.A.	m #5	0.00
LX Model	N.A.	m #5	0.00
#R&R Complete			
3 Trim, Center Body	78512-SSD-A61ZM	m	1.85
4 Plate, Horn	78502-SSD-A61	m	5.55
5 Module, Driver Air Bag-See Air Bag System Section	38710-SSA-A01ZM	m	3
6 Reel, Cable-See Air Bag System Section	78500-SSD-A01	m	21.53
7 Damper, Vibration	38710-SSA-A01ZM	m	19.20
8 Switch, Cruise Control	78512-SSD-A61	m	1.45
9 Plate, Switch	78512-SSD-A61	m	1.45

COLUMN

R&L Steering Column	m 1.3
O/H Steering Column (Includes R&L)	m 2.3



1 Column, Steering	53000-SSD-A01	m 2.3	296.30	
2 Joint, Lwr Column	53323-SSA-003	m #8	34.17	
3 Cover, Upper Column	77350-SSA-A01ZM	m #3	4.88	
4 Cover, Lower Column	77360-SSA-A01ZM	m #3	12.73	
#R&R Complete				
5 Label, Connector Location ¹	89001-SSA-000	m	1.55	
<i>1 Included w/Lower Steering Column Assy</i>				
6 Body Assy, Switch	01	36251-SSA-V01	m #3	352.35
	02	36251-SSA-A51	m #1	30.88
7 Bracket, Body, Switch		36257-SSA-J01	m	8.28
<i>1 Included w/Switch Body Assy</i>				
8 Switch, Headlamp	36255-SSA-A02	m #6	27.20	
9 Switch, Wiper	36256-SSA-A01	m #6	20.40	
#R&R Complete				
10 Lock Assy, Steering				
DX, LX Model				
Man Trans	01	35100-SSA-A01	m 1.1	139.85
	02	35100-S7A-K01	m 1.1	221.97
Auto Trans	01	35100-SSA-A51	m 1.1	152.12
	02	35100-S7A-H01	m 1.1	248.40
EX Model				
Man Trans	01	35100-SSA-A12	m 1.1	228.57
	02	35100-SSP-A11	m 1.1	294.08
Auto Trans	01	35100-SSA-A62	m 1.1	255.00
	02	35100-SSP-A61	m 1.1	294.08
HX Model				
Man Trans	01	35100-SSA-A01	m 1.1	139.85
	02	35100-S7A-K01	m 1.1	221.97
Auto Trans	01	35100-SSA-A51	m 1.1	152.12
	02	35100-S7A-H01	m 1.1	248.40
Canada				
DX, LX Model				
Man Trans	01	N.A.	m 1.1	0.00
	02	N.A.	m 1.1	0.00
Auto Trans	01	N.A.	m 1.1	0.00
	02	N.A.	m 1.1	0.00
SI Model				
Man Trans	01	N.A.	m 1.1	0.00
	02	N.A.	m 1.1	0.00

HONDA CIVIC COUPE 2001-02

STEERING WHEEL/COLUMN Cont'd

COLUMN Cont'd

Auto Trans	01 N.A.	m 1.1	0.00
	02	m 1.1	0.00
11 Immobilization Unit ¹	39730-SSA-A01	m 1.1	7.22
12 Switch, Ignition ²	35130-SSA-J51	m	57.96
13 Bracket, Steering Lock ¹	35106-S30-003		2.05
14 Bolt, Steering ²	35102-SV4-003		.57


¹Included w/Steering Lock Assy

ENGINE

Use Procedure Explanation 12 with the following text.

R&I Engine/Trans Assy	m 7.3
Add to R&I Engine/Trans Assy	m 5
w/HC	

ENGINE/TRANS MOUNTS



1 Mount Assy, Front Eng ²	50620-SSA-013	.7	64.70
2 Insulator, Front Eng ²	50627-SSA-003	103.15	
¹ Included w/Front Engine Mount Assy			
3 Mount, Trans			
USA			
DX, EX, LX Model	01 50906-SSA-033	.7	41.10
	02 50895-SSA-A01	.7	55.72
HX Model			
Man Trans	01 50895-SSA-033	.7	41.10
Auto Trans	02 50895-SSA-A01	.7	55.72
Canada			
Man Trans	01 50895-SSA-991	.7	53.67
Auto Trans	02 50895-SSA-992	.7	53.67
N.A.		.7	0.00

4 Bracket, Trans Mount

USA

DX, EX, LX Model

HX Model

Man Trans

Auto Trans

Canada

Man Trans

Auto Trans

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.

N.A.


N.A.

2 Hose, Outlet ¹	17241-PLC-000	3.85
3 Hose, Inlet ¹	17228-PLC-000	4.07
4 Insulator, Housing ¹	17213-P13-000	2.25
5 Insulator, Mounting ²	17212-PLC-000	2.28
6 Collar, Mounting ²	17216-PN2-000	2.62
7 Grommet, Sensor ¹	37861-PPA-000	2.28
¹ Included w/Lwr Air Cleaner Assy		
8 Element, Cleaner	17200-PLC-000	#2 12.65
9 Cover, Upr Air Cleaner	17211-PLC-000	#2 26.53
¹ R&I Complete		
10 Screw, Hold-Down		
5x20mm (8)	90091-P36-000	2.48
5x40mm	90091-PLC-000	2.07
11 Bolt, Air Cleaner (2)	90091-PPA-000	3.22
12 Bracket, Air Cleaner	17202-PLC-000	6.57
13 Sensor, Air Temp	37680-PLC-004	28.06
14 Tube, Breather	17153-PLC-000	4.65
15 Chamber, Resonator		
USA		
DX, LX, EX Model	17230-PLM-A00	.2 63.43
HX Model		
Man Trans	17230-PLM-A00	.2 63.43
Auto Trans	17230-PMP-A00	.2 59.22
N.A.		.2 0.00
16 Tube, Inlet	17244-PLC-000	.2 6.77
17 Hose, Inlet	17243-PLC-000	.2 10.15

EXHAUST

DX, LX MODEL

R&I Exhaust System Complete.....#1.0
¹Does Not Include R&I Exhaust Manifold or Shields



1 Manifold, Exhaust			
Man Trans	16160-PLM-A00	#1.0	708.42
Auto Trans	16160-PLM-AS0	#1.0	708.42
¹ Includes R&I Up & Lwr Oxygen Sensors			
2 Gasket, Exhaust Manifold			
Isrno	18115-PLC-J01	m	2.48
Nippon	18115-PLC-J02	m	8.43
3 Shield, Upper Heat			
Man Trans	18126-PLC-900		15.07
Auto Trans	18120-PLC-900		12.85
4 Shield, Lwr Frt Heat			
Man Trans	18161-PLC-900		16.43
Auto Trans	18161-PLC-J50		8.85
5 Shield, Lwr Rear Heat			
Man Trans	18162-PLC-900		13.77
Auto Trans	18162-PLC-900		4.70
6 Bracket, Manifold			
7 Sensor, Upr Oxygen	36531-PLM-A01	m #5	40.48
8 Sensor, Lwr Oxygen	36532-PLM-A01	m #5	40.48
9 Pipe, Frt Exhaust			
01 18220-SSD-A11		#	152.40
02 18220-SSD-A13		#	152.40
10 Gasket, Frt Pipe			
Chrome	18220-SSP-A11		10.70
11 Bracket, Sensor			
Man Trans	36533-PLD-000		1.87
Auto Trans	36533-PLD-P02		3.88
12 Hanger, Frt Pipe/Muffler			
18125-S84-A20			1.77
13 Shield, Upper			
174905-SSA-000			4.75
14 Muffler			
01 13030-SSP-A10		.7	170.00
02 N.A.		.7	0.00


ENGINE UNDER COVER



1 Shield, Under Engine			
Man Trans	74111-SSA-300	.3	26.95
Auto Trans	74111-SSA-300	.3	45.00
2 Clip, Shield (8)	91503-SZ3-003		2.08

AIR CLEANER

R&I Air Cleaner Assy.....3



1 Cleaner Assy, Lwr Air	17205-PLC-000	#4	47.73
¹ Includes R&I Element & Cover			


EX MODEL (USA)

SI MODEL (Canada)

R&I Exhaust System Complete.....#1.5
¹Does Not Include R&I Exhaust Manifold or Shields

Illustration Located in Next Column

1 Manifold, Exhaust	18100-PLR-000	#	123.73
2 Gasket, Exhaust			
Isrno	18115-PLC-J01	m	2.48
Nippon	18115-PLC-J02	m	8.43
3 Shield, Heat	18120-PLD-000		17.13
4 Pipe/Converter, Exhaust	18160-PLR-A00	#	1091.77
5 Gasket, Frt Pipe	18229-SSD-000		12.63
6 Sensor, Frt Oxygen	36532-PLR-A01	m #5	45.53
7 Sensor, Rear Oxygen	36531-PLR-A01	m #5	45.53




#R&R Both 8

8 Bracket, Frt Sensor	Man Trans	36533-PLD-000	1.87
	Auto Trans	36533-PLD-900	3.88
9 Hanger, Frt Pipe		18215-S84-A20	1.77
10 Shield, Upr Converter		18182-PLD-000	14.15
11 Shield, Lwr Converter		18181-PLD-000	39.33
12 Pipe, Center Exhaust		18220-S5D-A03	8 152.40
13 Shield, Frt Center Heat		74605-SSA-000	4.75
14 Shield, Rear Center Heat		74601-SSD-A00	11.25
15 Hanger, Center Pipe		18215-SSA-A11	1.62
16 Muffler		18030-SSP-A00	7 170.34
17 Extension, Muffler	Dealer Installed		
	Chrome	08F53-S5D-100	2 28.00
	Gold	08F53-S5D-100F	2 89.00
18 Shield, Muffler		17519-SSA-931	24.85
19 Support, Shield		17520-SSA-931	4.83
20 Hanger, Muffler (2)		18215-SSD-A01	1.62

HX MODEL

R&R Exhaust System Complete..... #15


#Does Not Include R&R Exhaust Manifold or Shields



1 Manifold, Exhaust	Man Trans	18160-PLM-A00 m #1.0	708.42
	Auto Trans	18160-PLM-A50 m #1.0	708.42
#Includes R&R Upr & Lwr Oxygen Sensors			
2 Gasket, Exhaust	Isuzu	18115-PLC-J01 m	2.48
	Nippon	18115-PLC-J02 m	8.43
3 Shield, Upper Heat	Man Trans	18120-PLC-000	15.07
	Auto Trans	18120-PLC-300	12.85
4 Shield, Lwr Frt Heat	Man Trans	18181-PLC-900	16.43
	Auto Trans	18181-PLC-150	6.85
5 Shield, Lwr Rear Heat	Man Trans	18182-PLC-000	13.77
6 Bracket, Manifold		11942-PLC-000	4.70
7 Sensor, Upr Oxygen		36531-PLC-003 m #4.5	257.52
8 Sensor, Lwr Oxygen		36532-PMP-A01 m #4.5	71.35
#R&R Both 8			
9 Pipe, Converter, Exhaust		18160-PMP-A00	8 685.57
10 Gasket, Frt Pipe		18229-S5D-A11	10.70
11 Sensor, Frt Pipe Oxygen		36536-PMP-A01 m	5 107.85
12 Bracket, Frt Sensor	Man Trans	36533-PLD-000	1.87
	Auto Trans	36533-PLD-900	3.88
13 Hanger, Frt Pipe		18215-S84-A20	1.77
14 Shield, Upr Converter		18182-PLD-000	14.15
15 Shield, Lwr Converter		18181-PLD-000	39.33
16 Pipe, Center Exhaust		18220-S5D-A03	8 152.40
17 Shield, Frt Center Heat		74605-SSA-000	11.05
18 Shield, Rear Center Heat		74601-SSD-A00	4.75
19 Hanger, Center Pipe		18215-SSA-A11	1.62
20 Muffler		01 18030-SSP-A00	7 170.34
		02 18030-SSP-A01	7 181.82

21 Extension, Muffler	Dealer Installed		
	Chrome	08F53-S5D-100	2 28.00
	Gold	08F53-S5D-100F	2 89.00
22 Shield, Muffler		17519-SSA-931	24.85
23 Support, Shield		17520-SSA-931	4.83
24 Hanger, Muffler (2)		18215-SSD-A01	1.62

EMISSION SYSTEM




1 Valve Assy, EGR		18011-PLM-A00 m	5 100.48
2 Gasket, EGRH	Included w/EGR Valve Assy	16715-PB2-000 m	4.97
3 Canister, Vapor		17011-SSA-A30 m	7 47.93
4 Sensor/Bknt Assy, Vent Press		04101-PLM-A00 m	3 138.67
5 Collar, Bushing(s) (2)		16923-S84-A00	.35
6 Bushing, Mounting (2)		17923-S84-A01	1.70

#Included w/Vent Press Sensor/Bknt Assy


ELECTRICAL

ALTERNATOR



1 Alternator Assy			
	USA	01 31106-PLM-A01RM m	1.3 R330.00
		02 01100-PLM-A02 m	1.3 0.00
	Canada	01 N.A.	m 1.3 0.00
		02 N.A.	m 1.3 0.00
2 Pulley, Alternator(s) (a)		31141-PLC-004 m	36.43
#Included w/Alternator Assy (a) Order by Application			
3 Bracket, Alternator		04111-PLC-305	#2 36.60
4 Stay, Alternator	Fw/Alternator Removed	31113-PLC-000	6.35
5 Belt, Alternator	Bando	31110-PLA-E01	5 8.24
	Mitsubishi	31110-PLA-E02	5 8.24

BATTERY




1 Battery		N.A.	4 0.00
2 Cable, Positive Battery-Serviced w/Engine Harness	Engine, Engine	32110-PLM-A00 m	198.67
3 Cover, Positive Terminal		32418-PLA-300	.92
4 Cable, Negative Battery			
	DX, EX, LX Model	32600-SSA-910	5 12.65
	HX Model		
	Man Trans	32600-SSA-910	5 12.65
	Auto Trans	32600-SSA-930	5 12.68
	Canada	N.A.	5 0.00
5 Cover, Battery		31531-SSA-A00	5.67
6 Tray, Battery		31521-SSA-000	3.58
7 Hold-Down, Battery	Base, Battery Tray-See Front Inner Section	31512-SSA-000	3.71
8 Rod, Hold-Down		31513-SM4-000	3.62

HORN

1 Horn		38100-S04-A01	.3 33.10
--------	--	---------------	----------

IGNITION

R&R Ignition Coils Complete..... m .5



1 Coil, Ignition (4)		30520-PGK-A01 m #2	45.90
	RFR All 5		
2 Sensor Assy, Crankshaft		37500-PLC-015 m 1.0	75.77
3 Grommet, Sensor	Included w/Crankshaft Sensor Assy	37500-PLC-015	1.92

4 Module, Control			
	2001		
	USA		
	DX, LX Model		
	w/California Emissions		
	Man Trans	37820-PLM-L02 m	7 341.22
	Auto Trans	37820-PLM-L51 m	7 650.00
	w/o California Emissions		
	Man Trans	37820-PLM-A01 m	7 431.28
	Auto Trans	37820-PLM-A51 m	7 640.59

	EX Model		
	Man Trans	37820-PLR-L02 m	7 500.00
	Auto Trans	37820-PLR-L52 m	7 500.00
	HX Model		
	w/California Emissions		
	Man Trans	37820-PMP-L02 m	7 500.00
	Auto Trans	37820-PMP-L52 m	7 500.00
	w/o California Emissions		
	Man Trans	37820-PMP-A01 m	7 393.95
	Auto Trans	37820-PMP-A52 m	7 525.33


	Canada		
	DX, LX Model		
	Man Trans	N.A.	m 7 0.00
	Auto Trans	N.A.	m 7 0.00
	SI Model		
	Man Trans	N.A.	m 7 0.00
	Auto Trans	N.A.	m 7 0.00

	2002		
	USA		
	DX, LX Model		
	Man Trans	37820-PLM-L04 m	7 500.00
	Auto Trans	37820-PLM-L54 m	7 500.00
	EX Model		
	Man Trans	37820-PLR-L04 m	7 352.30
	Auto Trans	37820-PLR-L54 m	7 510.38

	HX Model		
	Man Trans	37820-PMP-L03 m	7 500.00
	Auto Trans	37820-PMP-L63 m	7 500.00

	Canada		
	DX, LX Model		
	Man Trans	N.A.	m 7 0.00
	Auto Trans	N.A.	m 7 0.00
	SI Model		
	Man Trans	N.A.	m 7 0.00
	Auto Trans	N.A.	m 7 0.00

STARTER






1 Starter			
	USA		
	Denso	31200-PLR-A01RM m	9 R167.60
	Mitsuba	31200-PLM-A51RM m	9 R315.00
	Canada	N.A.	m 9 0.00

WINDSHIELD

Use Procedure Explanation 13 with the following text.

R&I Windshield..... #2.4
#Includes Clean Up Old Adhesive as Necessary





Refinish Fuel Filler Lid	4
R&R Both Quarter Panels	28.4
R&R Roof & Both Quarters	40.8
w/Sunroof	38.8
R&R Rear Body Panel & Both Quarter Panels	30.9
R&R Roof, Both Quarters & Rear Body Panel w/Sunroof	43.3
add to Sunroof	41.3
To R&I Quarter Panel	RL 2
To R&I Back Glass	RL 2

w/o Sunroof			
DX Model			
Beige	01 83200-SSP-A00ZB	2.0	173.42
	02 83200-SSP-A01ZB	2.0	170.85
Gray	01 83200-SSP-A00ZA	2.0	173.42
	02 83200-SSP-A01ZA	2.0	170.85
HX Model			
Beige	01 83200-SSP-A00ZB	2.0	173.42
	02 83200-SSP-A01ZB	2.0	170.85
Gray	01 83200-SSP-A00ZA	2.0	173.42
	02 83200-SSP-A01ZA	2.0	170.85
LX Model			
Beige	01 83200-SSP-A30ZB	2.0	173.42
	02 83200-SSP-A31ZB	2.0	170.85
Gray	01 83200-SSP-A30ZA	2.0	173.42
	02 83200-SSP-A31ZA	2.0	170.85
Canada			
w/o Sunroof			
	01 N.A.	2.5	0.00
	02 N.A.	2.5	0.00
w/o Sunroof			
DX Model			
	01 N.A.	2.0	0.00
	02 N.A.	2.0	0.00
LX Model			
	01 N.A.	2.0	0.00
	02 N.A.	2.0	0.00

2 Grip, Assist (2)			
Beige	R 83240-SSA-001ZB	2	13.57
Gray	01 83240-SSA-001ZA	2	13.57
	02 83240-SSA-001ZC	2	18.37
	R 83241-SSA-000	2	2.33

4 Lamp Assy, Frt Dome w/Sunroof			
Beige	34100-SSP-A01ZB	2	38.83
Gray	34100-SSP-A01ZA	2	38.83

5 Lens, Lamp w/Sunroof			
Gray	34251-SZ3-003	2	6.17

6 Bulb, Dome Lamp w/Sunroof (2)			
	34253-SZ3-003		.82

7 Lamp, Frt Dome w/o Sunroof			
Beige	34403-SSA-003ZB	2	28.93
Gray	01 34403-SSA-003ZA	2	825.33
	02 34403-SSA-003ZC	2	28.07

8 Lens, Lamp w/o Sunroof			
Beige	R 34401-SSA-003	2	2.22
Gray	L 34402-SSA-003	2	2.25

9 Bulb, Dome Lamp w/o Sunroof (2)			
	34253-671-003		2.22

10 Lamp Assy, Ctr Dome Beige			
	34250-SSP-A01ZB	2	21.75
	34250-SSP-A01ZA	2	21.75
	34251-SSP-A00	2	3.50
	34253-SSP-A01	2	2.76

SUNROOF

R&I Sunroof		#1.5	
O/H Sunroof (Includes R&I)		#3.0	
#w/Headliner Removed			

NOTE: All Parts in this section are included in overhaul unless noted otherwise.

Illustration Located in Next Column

1 Glass, Sunroof			
	R 70200-SSP-A01	1.0	479.02
2 Cover, Glass Stay			
	R 70620-SSP-A01	8.85	
	L 70625-SSP-A01	8.85	
3 Nut, Cover (2/Side)			
	R/L 94050-06000		.53
4 Cushion, Cover (2/Side)			
	R/L 70623-SB4-A01		.70
5 Shade Assy, Sun Beige			
	01 70900-SSP-A01ZB	7	123.25
	02 70900-SSP-A01ZB	7	131.13
	01 70900-SSP-A01ZA	7	123.25
	02 70900-SSP-A01ZA	7	131.13

6 Handle, Shade Beige			
	70611-SSA-J01ZB	1.39	
	01 70611-SSA-J01ZA	1.39	
	02 70611-SSA-J01ZC	1.39	


7 Stopper, Glass (2)			
	#Included w/Sun Shade Assy		
8 Protector, Roof			
	70630-SSP-A01	41.75	
9 Frame, Sunroof			
	01 70100-SSP-A01	#3.0	198.25
	02 70100-SSP-A01	#3.0	222.45

#w/Headliner Removed			
10 Hose, Drain			
Front	R/L 70050-SSD-A00	4.40	
Rear	R/L 70060-SSA-J00	5.32	

11 Valve, Drain Front			
	R/L 70052-S30-000	6.55	
	R 70082-SB4-A00	3.75	
12 Seat, Side Frame			
	R 70082-SSA-J01	2.55	
	L 70087-SSA-J01	2.52	
13 Seal, Front Frame			
	R/L 70081-SB4-A01	1.30	
14 Cable, Sunroof			
	01 70370-SSA-J01	#3.0	207.07
	02 70370-SSA-A01	#3.0	0.00
#w/Headliner Removed			
15 Channel, Frt Drain			
	R 70240-SSA-J01	22.35	
16 Slider, Cable			
	R 70242-SSA-J01	7.60	
	R 70247-SSA-J01	7.60	
	L 70087-SSA-J01	8.8	
17 Shift, Frame			
	01 70450-SSA-J01	#4	125.00
	02 70450-SSP-A01	#4	113.43
#w/Headliner Removed			
19 Bracket, Cable			
	R 70142-SSA-J01	5.7	
	L 70147-SSA-J01	5.7	

BACK WINDOW

Use Procedure Explanation 19 with the following text.
R&I Back Window Glass #2.3
#Includes Clean Up Old Adhesive as Necessary



1 Glass, Back Honda-Green				
	73211-SSP-A01	#2.0	356.65	
	NAGS-Green	FB21177GTN	#2.0	948.50
#Includes Clean Up Old Adhesive as Necessary				
2 Clip, Upper				
	R/L 91568-SM-A01		5.60	
3 Clip, Lower				
	R/L 91567-SM-A01		2.53	
4 Fastener, Upper				
	01 R/L 91563-SV4-003		3.67	
	01 R/L 91568-SV4-003		3.25	


QUARTER PANEL

Use Procedure Explanations 20 and 26 with the following text.

#w/Headliner Removed			
SHEET METAL			
Refinish Quarter Panel Outside	R/L	2.3	
Add to Edge Panel	R/L	.5	
Add to Pillar	R/L	.5	

1 Panel Assy, Quarter			
	R 04630-SSP-A00ZB	#16.0	447.48
	L 04645-SSP-A00ZB	#16.5	460.22
#Includes 4 w/Roof Removed, Deduction Includes Common Surfaces & Included Operations			
2 Panel, End			
	R 63200-SSP-A00ZB	2.0	47.92
	L 63200-SSP-A00ZB	2.0	35.58
3 Support, Fuel Filler			
	R 63915-SSP-A00ZB		11.38
4 Panel Assy, Inr Quarter			
	R 64300-SSP-A00ZZB	8.5	269.63
	L 64700-SSP-A00ZZB	8.5	275.00
5 Wheelhouse			
	R 65300-S3D-A00ZB	3.5	153.00
	L 64700-SSP-A00ZZB	3.5	153.00
#Included w/Inr Quarter Panel Assy			
6 Lid, Fuel Filler			
	R 70495-682-000		1.95
7 Cushion, Lid (2)			
	L 74404-SB4-A01		15.37
8 Spring, Lid			
	L 75450-S10-000		15.37
9 Outlet, Air			
Mudguard Set-See Front Panel Section			
	10 Panel, Package Tray	65300-S3D-A00ZB	-157.72
	R 66291-SSP-A00ZB		12.77
	L 66291-SSD-A00ZB		12.77

INTERIOR TRIM



1 Trim Assy, Rear Pillar Beige			
	R 84131-SSP-A01ZB	#9	4.40
	L 84181-SSP-A01ZB	#9	4.40
	R 84131-SSP-A01ZA	#9	4.40
	L 84181-SSP-A01ZA	#9	4.40
#Includes R&R Quarter Panel Trim Assy			

2 Clip, Trim (a)			
	R/L 91560-SB4-A01		1.57
(a) As Required			

3 Cap, Rear Trim			
	R 84133-SSP-A01ZB		7.77
	R 84133-SSP-A01ZA		7.77

4 Cover, Harness			
	R 84183-SSP-A01ZB		7.77
	L 84183-SSP-A01ZA		7.77


5 Trim Assy, Quarter Panel Beige			
	01 83730-SSP-A01ZB	#7	69.13
	02 83780-SSP-A01ZB	#7	68.12
	01 83730-SSP-A01ZA	#7	63.63
	02 83780-SSP-A01ZA	#7	44.12
	01 83780-SSP-A01ZB	#7	69.13
	02 83780-SSP-A01ZA	#7	69.13

#Includes R&I Rear Seat Assy			
6 Armrest Beige			
	01 R 83731-SSP-A00ZB		16.37
	L 83781-SSP-A00ZB		16.37
	02 R 83731-SSP-A00ZC		16.13
	L 83781-SSP-A00ZC		16.37
	01 83781-SSP-A00ZA		16.13
	02 83781-SSP-A00ZA		16.37

7 Support, Armrest Black			
	R 83732-SSP-A00ZB		16.37
	L 83782-SSP-A00ZB		16.37

REAR LAMPS Cont'd

LICENSE LAMP Cont'd



032-03169

HIGH MOUNT STOP LAMP



032-01779


- 1 Lamp, Stop-1-See Quarter Panel Section
 - 2 Socket, Bulb-1-See Quarter Panel Section
 - 3 Bulb, Stop-1-See Quarter Panel Section
- Included w/Package Tray Assy-Listed in Quarter Panel Section

REAR BUMPER

Use Procedure Explanations 27 and 28 with the following text.

Refinish Rear Cover	2.2
Refinish Bumper Cap	R/L .4
R&I Bumper Assy	.8
O/H Bumper Assy (Includes R&I)	1.2

NOTE: All Parts in this section are included in overhaul unless noted otherwise.



032-03335

1 Cover, Rear (P)	04715-SSP-A0ZZ	1.2	198.70
2 Cap, Bumper (P)	R/L 71503-SSA-000	.1	1.78
3 Clip, Bumper (3)	91503-SZ3-003		2.08
4 Bolt, Bumper (2)	80119-SE3-000		2.48
5 Grommet, Bumper (3/Size)	R/L 90882-SS9-003		5.79
6 Spacer, Upper Bumper	R 71504-SS9-A00		7.99
7 Spacer, Side Bumper	R/L 71509-SSP-A00		4.15
8 Absorber, Bumper	R/L 71593-SSA-000		50.95
9 Reinforcement, Bumper	R/L 71596-SSA-000		50.95
	71570-SSD-A00	IOH	30.95
	71530-SSD-A0ZZ	#3	102.50

#w/Bumper Removed, Not Included in O/H

10 Nameplate (Adhesive)			
DX			
Factory Installed Dealer Installed	75723-SSP-A30		2. 7.38
Gold	08F19-SSP-100H		2. 12.00
11 EX			
Factory Installed Dealer Installed	75723-SSP-A10		2. 7.38
Gold	08F19-SSP-100F		2. 12.00
12 HX			
Factory Installed Dealer Installed	75723-SSP-A00		2. 7.38
Gold	08F19-SSP-100		2. 12.00
13 LX			
Factory Installed Dealer Installed	75723-SSP-A20		2. 6.98
Gold	08F19-SSP-100G		2. 12.00
14 SX			
Canada	N.A.		2. 0.00

HONDA CIVIC SEDAN 2001-02

SECTION INDEX

A/C Heater/Ventilation	359
A/C Refrigerant Capacities	359
ABS/Brakes	361
Air Bag System	361
Air Cleaner	364
Back Window	374
Center Console	367
Clear Coat Identification	358
Cooling	359
Owl & Dash	385
Cruise Control System	361
Electrical	385
Emission System	364
Engine	364
Engine Under Cover	364
Engine/Trans Mounts	364
Exhaust	364
Front Bumper	369
Front Door	369
Front Drive Axle	362
Front Fender	360
Front Inner Structure	360
Front Lamps	359
Front Seat	368
Front Steering Linkage/Gear	363
Front Suspension	362
Fuel Tank	376
Grille	358
Hood	359
Information Labels	358
Instrument Panel	366
Luggage Lid	374
Paint Code Location	358
Quarter Panel	374
Rear Body	376
Rear Bumper	377
Rear Door	371
Rear Lamps	376
Rear Seat	369
Rear Suspension	375
Rocker/Pillars/Floor	367
Roof	373
Seat Belts	369
Special Cautions	358
Steering Pump	363
Steering Wheel/Column	363
Sunroof	374
Underhood Dimensions	350
Wheel	362
Windshield	365

SPECIAL CAUTIONS

SRS

SUPPLEMENTAL RESTRAINT SYSTEM

Refer to Procedure Explanation 29 for Supplemental Restraint/Air Bag Special Cautions.

SUSPENSION

Manufacturer advises that some new fasteners must be used whenever old fasteners are loosened or replaced.

PAIN CODE LOCATION

Paint code located on left door lock pillar.


CLEAR COAT IDENTIFICATION

All colors are clear coat.

INFORMATION LABELS

Illustration Located in Next Column

1 Label, SRS Warning		
w/Side Air Bag	77871-SZ3-A60	2.35
w/No Side Air Bag	77871-SLD-A80	8.97
2 Label, Specification		
DX, LX Model	42762-SSD-A50	1.60
EX Model	42762-SSD-A00	1.60



032-03039

3 Label, Side Air Bag	R/L	78031-SZ3-A80	1.98
4 Label, SRS Caution		78527-S04-A82	1.98
5 Label, A/C Caution		80050-SP3-H00	1.30
Label, Spare Tire Caution		42767-SSA-A00	25
Label, LEV	R/L	75717-SSD-A00	5.73


Label, Cap-See Cooling Section
Label, Connector Location-See Steering Wheel/Column Section
Label, Immobilizer-See Front Door Section

FRONT BUMPER

Use Procedure Explanations 1 and 28 with the following text.

Refinish Front Cover	2.1
Refinish Reinforcement Bar	1.0
Reinforce Bumper Spooler	.8
R&I Bumper Assy	1.1
O/H Bumper Assy (Includes R&I)	2.0
Add to R&I or O/H Front Bumper w/Spooler	.3

NOTE: All Parts in this section are included in overhaul unless noted otherwise.




032-03034

1 Cover, Front (P)	04711-SSP-A0ZZ	2.0	198.70
(P) Paint to Match			
2 Frame, License Plate	R/L 71145-SSA-A00	.2	9.07
3 Bolt, Cover (2/Size)	R/L 71140-SSD-A00		1.0
4 Filter, Bumper	R 71190-SSA-000	IOH	17.96
	L 71190-SSA-000	IOH	17.96
	R 71193-SSA-000		2.22
	L 71196-SSA-000		2.80
5 Stay, Side Bumper	R/L 91503-SZ3-003		2.08
6 Clip, Side	R/L 71170-SSD-A00		58.05
7 Absorber, Impact	R/L 71130-SSA-00ZZ		117.18
8 Bar, Reinforcement			
#w/Bumper Assy Removed, Not Included in O/H			
9 Spooler, Bumper (P)	71110-SSA-A0ZZA	.3	20.30
(P) Paint to Match			
10 Clip, Spooler (2)	91503-SZ3-003		2.08
11 Damper, Front Bumper	71185-SSA-A01		13.33

GRILLE

Refinish Grille	1.0
R&I Grille Assy	#1.2

Includes R&I Bumper Assy



032-03041

1 Grille		
Cover Green Pearl		
Code G95P	71121-SSA-0030C	#1.2 55.13
Etamel Blue Pearl		
Code B95P	71121-SSA-0032B	#1.2 55.13
Nighthawk Black Pearl		
Code B92P	71121-SSA-0032A	#1.2 55.13